

# **OEM**<sup>®</sup>

Tools for Professionals

## **6 Piece Noid Lite Set 27161**

**OEM**<sup>®</sup>  
Tools for Professionals

### **6 Piece Noid Lite Set**

**27161**

1. Disconnect electrical harness from injector.
2. Plug NOID LITE into harness and turn engine on.
  - a. If Noid Lite flashes, electrical system is OK and the problem is in the injector of fuel system.
  - b. If no steady light appears, this indicates an electrical malfunction and you should check the diagnostic charts. 8/07

Used to check electrical impulses from the wiring harness to the fuel injectors.

Includes GM TBI, GM SCPI, GM PFI, Ford TBI, GEO TBI, Bosch PFI.

Caution: Always wear safety glasses



**MADE IN CHINA**