

OEM®

Tools for Professionals

Ball Joint Adapter Set 27164

OEM®

Tools for Professionals

Ball Joint Adapter Set

- For: 1980-2000 Model
Honda Accord, Civic,
DelSol, Crx and Preludes

Ball Joint Removal and Installation:

This tool set is designed for use on most cars that press-fit type ball joints. It will help user remove and install ball joints without the need to remove the control arm from the vehicle. Adapters are used with #27023 ball joint press.

27164

REMOVAL:

1. Assemble the ball joint press over the control arm.
2. Tighten the forcing screw until the removing adapter contacts the control arm. Check the alignment of all tooling and components, and continue tightening the forcing screw until the ball joint is removed.

INSTALLATION:

1. Clean the control arm and coat the I.D. with a suitable lubricant.
2. Insert the replacement ball joint as a straight as possible into the vehicle control arm.
3. Assemble the all joint press components and tighten the forcing screw. Check the alignment of all tooling and components, and continue tightening the forcing screw until the ball joint is firmly seated. 8/07

Caution: Always wear safety glasses



MADE IN TAIWAN